

gresham house

3250 Ridgeway Dr. Unit 6
Mississauga, Ontario
L5L 5Y6
P 905 412 0362
F 905 412 0365



Lars Chair 1/2– 37”L



Standard features:

3.5” Pullover Arm and Back

Seam with Balloon Seat and Knife Back w/ Sewn Kiss Pleat

Welt along outside back & Arm, not base

Cushioning (1 Seat, 1 Back): Standard Seat, Feather Back

Self Decking

Show wood:

Applied #0109 Bun Leg

Wood species: Maple

Standard Stain Finish: Medium Ebony (see guide for other options)

COM required: (plain Fabric): 11 yards

Note: see guide for required patterned fabric

COL required: 187 sq ft, Leather not recommended for Multi loose back pillows.

Available options (see Guide):

nail head

Shallow Comfort: #5701 Chair 1/2

Outside Dimensions: 37”W x 39”D x 34”H

Inside dimensions:

Seat Depth: 22.5” Seat Width: 29”

Seat Height: 18” Arm Height: 24”

Frame Height: 30”

Deep Comfort: #5700 Chair ½ (As Pictured)

Outside Dimensions: 37”W x 41”D x 34”H

Inside dimensions:

Seat Depth: 24.5” Seat Width: 29”

Seat Height: 18” Arm Height: 24”

Frame Height: 30”

Please Note: tolerance of 1” is industry standard

gresham house

3250 Ridgeway Dr. Unit 6
Mississauga, Ontario
L5L 5Y6
P 905 412 0362
F 905 412 0365



Lars - Large 81"L



Standard features:

3.5" Pullover Arm and Back

Seam with Balloon Seat and Knife Back w/ Sewn Kiss Pleat

Welt along outside back & Arm, not base

Cushioning (2 Seats. 2 Backs): Standard Seat, Dacron Back

Self Decking

Show wood:

Applied #0109 Bun Leg

Wood species: Maple

Standard Stain Finish: Medium Ebony (see guide for other options)

COM required: (plain Fabric): 19 yards

Note: see guide for required patterned fabric

COL required: 323 sq ft, Leather not recommended for Multi loose back pillows.

Available options (see Guide):

nail head

Shallow Comfort: #5701 Large Sofa

Outside Dimensions: 81"W x 39"D x 34"H

Inside dimensions:

Seat Depth: 22.5" Seat Width: 73"

Seat Height: 18" Arm Height: 24"

Frame Height: 30"

Deep Comfort: #5700 Large Sofa (As Pictured)

Outside Dimensions: 81"W x 41"D x 34"H

Inside dimensions:

Seat Depth: 24.5" Seat Width: 73"

Seat Height: 18" Arm Height: 24"

Frame Height: 30"

Please Note: tolerance of 1" is industry standard

gresham house

3250 Ridgeway Dr. Unit 6
Mississauga, Ontario
L5L 5Y6
P 905 412 0362
F 905 412 0365



Lars XL Sofa – 95”L



Standard features:

3.5” Pullover Arm and Back

Seam with Balloon Seat and Knife Back w/ Sewn Kiss Pleat

Welt along outside back & Arm, not base

Cushioning (2 Seats. 2 Backs): Standard Seat, Dacron Back

Self Decking

Show wood:

Applied #0109 Bun Leg

Wood species: Maple

Standard Stain Finish: Medium Ebony (see guide for other options)

COM required: (plain Fabric): 21 yards

Note: see guide for required patterned fabric

COL required: 357 sq ft

Available options (see Guide):

Nail head, welt

Shallow Comfort: #5701 XL Sofa

Outside Dimensions: 95”W x 39”D x 34”H

Inside dimensions:

Seat Depth: 22.5” Seat Width: 87”

Seat Height: 18” Arm Height: 24”

Frame Height: 30”

Deep Comfort: #5700 XL Sofa (As Pictured)

Outside Dimensions: 95”W x 41”D x 34”H

Inside dimensions:

Seat Depth: 24.5” Seat Width: 87”

Seat Height: 18” Arm Height: 24”

Frame Height: 30”

Please Note: tolerance of 1” is industry standard